HOW TO SET UP SYMBAIN PHONES TO VIEW Q-See DVR SYSTEMS ONLINE

MODEL NUMBERS:
QSD2316L, QSTD2408, QSTD2416, QSDT8DP

Prior to setting up your phone to view your cameras, your DVR must be set up for remote viewing.

STEP 1: On your phone, run your web browser.

STEP 2: Under "Bookmarks", input your router's external IP address in a new bookmark. Click on this bookmark to access your DVR.



STEP 3: A welcome screen will appear; click on the “install package” link.



STEP 4: Click “Yes”.



STEP 5: On the System Menu screen, open the SCam icon.

STEP 6: Click on "Options".



STEP 7: Enter the external IP address from your router in the "Server" line. Under "Username" and "Password", enter in the login information and click "OK".

STEP 8: Your phone will start connecting to your DVR.



STEP 9: Your phone will display one camera channel at a time. If you wish to change cameras, click on “Options” and go to “Camera Options”.